



24VOLT MDB WIRING

(updated 6/8/11)

- 1) Red to OV on the top left of PLC
- 2) Brown to XO or X3(which ever lights up when you push the credit button in) on the bottom left of PLC
- 3) Orange to #2 on Y6 Blocker Relay
- 4) Black to #6 on Y6 Blocker Relay
- 5) White from harness goes to #4 on the new contact added to the Bag Switch and jumps to #4 on the new contact added to the Bulk Switch
- 6) Add a wire from #2 on Blocker Relay to #3 on the new contact added to the Bag Switch and jumps to #3 on the new contact added to the Bulk Switch
- 7) Green, Yellow, and Blue wires are not used
- 8) Transformer Wiring : One of the Black wires go to the bottom of the 2amp fuse
The other Black wire goes to the Neutral on the terminal strip
Green wires from the transformer connect in the end of the 12 pin harness were there are 2 empty pins.